

9.6 Cruise Performance

Typical Cruise Envelope

- Altitude: **FL320 - FL390**
 - Speed: **Mach 0.76 - 0.80**
-

Efficiency Considerations

- Higher altitude → lower fuel burn
 - Managed speed → optimal performance
-

Monitoring Requirements

Pilots must monitor:

- Fuel consumption
 - Wind conditions
 - Flight progress
-

Core Rule

“Cruise is about efficiency, not speed.”

Revision #1

Created 2026-03-23 19:52:47 UTC by Jonas

Updated 2026-03-23 19:52:56 UTC by Jonas