

9.7 Descent Performance & Energy Management

Descent Characteristics

- Typically flown at idle thrust
 - Vertical path controlled manually (VA SOP)
 - Speed managed automatically
-

Energy State Awareness

Pilots must continuously assess:

- Altitude vs distance
 - Speed vs configuration
-

High Energy Situation

- Too fast / too high

Correction methods:

- Increase descent rate
 - Use speed brakes
-

Low Energy Situation

- Too slow / too low

Correction methods:

- Reduce descent rate
 - Increase thrust
-

Core Rule

“Energy must be managed early - not corrected late.”

Revision #1

Created 2026-03-23 19:53:05 UTC by Jonas

Updated 2026-03-23 19:53:41 UTC by Jonas