

3.3 Main Instrument Panel

This is the primary area for flight control and monitoring.

Primary Flight Display (PFD)

Displays essential flight data:

- Attitude (pitch & bank)
 - Airspeed
 - Altitude
 - Vertical speed
-

Navigation Display (ND)

Shows:

- Flight plan route
 - Weather radar (if active)
 - Navigation aids
 - Terrain (if enabled)
-

ECAM Displays

The ECAM system consists of two screens:

- **Upper ECAM (E/WD):**
 - Engine parameters
 - Warning and status messages
- **Lower ECAM (SD):**
 - System pages (e.g. HYD, FUEL, ELEC)

Purpose:

To provide automatic system monitoring and assist pilots in abnormal situations.

Revision #1

Created 2026-03-23 15:44:21 UTC by Jonas

Updated 2026-03-23 15:44:39 UTC by Jonas