

5.9 Landing

☐☐ PM Flow

- Gear → DOWN
 - Flaps → FULL
 - Speed → CHECK
-

☐☐ PF Flow

- Stabilize approach
 - Monitor FD
-

☐ Landing Checks

- Gear → DOWN
 - Flaps → FULL
 - Speed → CHECKED
-

Revision #2

Created 2026-03-23 17:00:41 UTC by Jonas

Updated 2026-05-27 22:52:57 UTC by Jonas