

6.2 INIT A Page

Used for basic flight initialization.

Required Entries:

- FROM / TO → Departure & Destination
- FLT NBR → Flight Number
- COST INDEX → Airline value
- CRZ FL → Planned cruise level

Key Rule

All entries must be cross-checked by PM

Revision #1

Created 2026-03-23 17:09:30 UTC by Jonas

Updated 2026-03-23 17:09:41 UTC by Jonas